


875 AC Z1 00 60



www.camar.it/warning

Fe


800
 19200
 1600



875 AC Z1

- 0 1 0 7
- 0 1 5 7
- 0 2 0 7
- 0 2 5 7
- 0 3 0 7
- 0 3 5 7
- 0 4 0 7
- 0 4 5 7
- 0 5 0 7
- 0 5 5 7
- 0 6 5 7
- 0 7 0 7
- 0 7 5 7
- 0 8 5 7
- 0 9 5 7
- 1 1 5 7

Lmm



www.camar.it/warning

Fe

1200

